



Transmitter



- ① External Antenna
- ② Power/Signal indicator
- ③ LCD battery status
- ④ LCD channel lock
- ⑤ LCD selected channel
- ⑥ Aux-in socket
- ⑧ Power button
- ⑦ Up/Down button
- ⑨ Inbuilt microphone
- ⑩ Mic-in socket
- ⑪ Mute/Sync button
- ⑫ Lanyard tie-up

Receiver



- ① External Antenna
- ② Power/Signal indicator
- ③ LCD battery status
- ④ LCD channel lock
- ⑤ LCD selected channel
- ⑥ Volume wheel
- ⑦ Up/Down button
- ⑧ Power button
- ⑨ Earphone socket

Setup/Installation

Power on/off

- Press and hold power button for 1 sec. to power the device on. LCD screen shows "0" and then last used channel.
- Press and hold power button for 2 sec. to power the device off. LCD screen shows "OFF" and then shuts down.

Channel lock/unlock

- Channel will automatically be locked and symbol " " shows up if the device is idle for 5 seconds after being turned on.
- To unlock the channel, press buttons Δ and ∇ simultaneously for 2 seconds until symbol " " disappears.

Channel selection

- Press button Δ or ∇ to select preferred channel when channels are unlocked.

Power saving (receiver only)

- Power of receivers will be off if no signal is received for 20 minutes.

Sensitivity adjustment (transmitter only)

- When channel is locked, press and hold Δ for 2 seconds to enter mode $\text{U} \text{S} \text{U} \text{I}$.
- Press button Δ and ∇ to adjust the sensitivity (default: $\text{U} \text{S} \text{U} \text{I} \sim \text{U} \text{S} \text{U} \text{I}$).
- Press power button to confirm the setting.

Power/Signal indicator

Indicator behavior		Transmitter	Receiver
Flash	Red	Low battery & Mute activated	—
	Blue	Sufficient battery & Mute activated	—
	Purple	Sync activated	—
Steady	Red	Low battery & Signal transmitted	Low battery & Signal received
	Blue	Sufficient battery & Signal transmitted	Sufficient battery & Signal received
No LED		Device is not turned on	Signal is not received

Channel synchronization

- Press mute/sync button on transmitter before it is on.
- Turn the transmitter on and purple LED flashes to indicate the activation of channel-sync mode.
- Turn receiver(s) on to be channel synchronized (one or multiple receivers can be turned on at the same time).
- When channel is successfully synchronized, receiver's LCD shows same channel as that of transmitter's and its LED turns steady blue.
- Press mute/sync button of transmitter again to escape from sync setup.

Note

1. To re-activate channel-sync mode, please turn the transmitter off and follow above steps again.
2. After the transmitter escapes from channel-sync mode, its sound will be muted when mute/sync button is pressed.
3. If the channel is not successfully synchronized, turn receiver(s) off and then on again to be re-synchronized.
4. Maximum synchronized range is 1 meter. Out of the limited range might result in failed connection.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice:
The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:
To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

FCC INFORMATION
The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraphs:
The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

※ Specifications are subject to change without prior notice.